# pi-top HARDWARE

Hardwiring the pi-top to Further

1 **Plug the USB-C end** of the cable **into the port marked in green** on the pi-top.

The provided cable has a little groove which must be facing down, aligned with the notch on the green-rimmed port on the pi-top[4]

**2** **Plug the USB-A end** of the cable **into your computer or laptop.**

USB-A End of the Cable

3 **Press the blue down arrow** on the pi-top, until you see *Network,* then press select.

Network

Press the blue down again until you see *USB with an IP address.*

USB
192.168.192.169

4 On your device open a tutorial. At the bottom right of the page **find and click on the pi-top icon.**

5 In the "Device IP Address" box, **type the USB address shown on your pi-top.** The periods must be entered.

Device IP Address

6 **Click connect.** The word "connect" should change to "disconnect" when the connection is successful.

Your Device
192.168.192.169   Connect
Other Devices